Triplex Plunger Pump, Solid Shaft, 1750 RPM

FEATURES

- Triplex plunger pump
- New Forged brass manifold, increases working pressure to 4,000 PSI
- New plunger guide bushing (patent pending)
- Solid ceramic plungers with dual guide system
- New dual diameter plunger guide
- New optimized outlet valves
- New dual lip oil seal



SPECIFICATIONS

Pump Model	EP1510S17	EP1512S17	EP1513S17	EP1810S17	EP1811S17	EP1812S17	EP1813S17	EP1313S17
Maximum Volume	2.4 GPM	2.9 GPM	3.2 GPM	3.4 GPM	3.7 GPM	4.0 GPM	4.2 GPM	2.4 GPM
Maximum Discharge Pressure	3,045 PSI			2,500 PSI			2,900 PSI	4,000 PSI
Horsepower	4.9 HP 6.0 HP 6.5 HP		6.5 HP	5.7 HP	6.2 HP	6.6 HP	8.3 HP	6.4 HP
Maximum Pump Speed	1750 RPM							
Maximum Inlet Pressure	125 PSI							
Max. Inlet Vacuum	3 ft. water (2.6 Hg)							
Plunger Bore (in / mm)	.591 in./15 mm			.709 in./18 mm				.512 in./13 mm
Plunger Stroke (in / mm)	.394 in./10 mm .472 in./12 mm .512 in./13 mm		.512 in./13 mm	.394 in./10 mm	.433 in./11 mm	.472 in./12 mm	.512 in./13 mm	.512 in./13 mm
Oil Capacity	15 oz.							
Maximum Fluid Temperature	165º F							
Inlet Port Thread	1/2"-14 BSP-F							
Discharge Port Thread	3/8"-19 BSP-F							
Shaft Diameter	.945 in./24 mm							
Weight	15.4 lbs.							
Dimensions - Nominal	9.5"x8.38"x5.1"							







Instructions and Recommendations for the Installation of EP Series Pumps

Maximum temperature of the water through the pump is 165°F (85°C).


In order to obtain maximum performance in terms of duration of seals and valves, it is necessary to respect a few simple rules, as follows:

1) In order to avoid damage caused by cavitation, the pump must be pressure fed.

The higher the inlet pressure, the longer the life of the wet end of the pump.

When working at 185°F (85°C), the minimum feed pressure - measured directly in the inlet port of the pump when it is working - is 45 psi (3 bar).

The minimum feed pressure according to the different temperatures are:



Naturally, if the application allows for feeding the pump with 45 psi (3 bar) even at low temperatures (for example: 115°F/45°C the life of the wet end of the pump will be even longer.

- 2) The plumbing which feeds the pump must be of a diameter at least equal to the inlet port. Also, follow the suggestions below:
 - a) Make the plumbing as short and straight as possible, preferably in an upward direction to facilitate the expulsion of eventual air bubbles naturally if compatible with the requirements of the system.
 - b) It is always useful to put a filter at the inlet with capacity of 4 to 5 times the flow of

the pump, for example for a 4 gpm (15 l/min) pump, put a filter from 16 to 20 gpm (60-75 l/mi)The mesh size suitable for this application is 0.016" (.4 mm).

c) It is extremely important to put a pressure switch on the suction port of the pump, and in any case downstream from the filter, so that it can stop the pump should the feed pressure drop by 20% due to the filter clogging or failure of the feed pump, etc.

3) Change of oil

We recommend the *first oil change after the first 50 hours*, with the *pump stopped* and the *oil still warm*.

This change is not recommended because the oil has lost its properties, but rather to eliminate the impurities that have gotten into the oil during the running-in phase. If these impurities are not removed, but are allowed to remain in the oil, they may cause premature wear to the moving parts and the oil seals. After this initial change, the oil can then be changed every three months or 300 hours of operation thereafter.


Please note: If the pump works in conditions with high humidity and with sharp temperature changes, it is possible that condensation will appear inside the crankcase, which mixing with the oil can change its properties. This is easy to see because the oil changes to a white, milky color.

If the pump does not have excessive water leaking from the packings, and the oil becomes milky, the oil has to be changed more frequently. The percentage of water in the oil must not exceed 20%.

Use oil per the following chart:

CHART OF COMPATIBLE OILS SAE15W40							
General Pump	Series 100						
BP	VISCO 2000						
CASTROL	CWX						
MOBIL	SUPER						
SHELL	HELIX SUPER						
TOTAL	QUARTZ 4000-5000						

EP SeriesSolid Shaft - 1750 RPM



TIEM	10x29.5 3 and 3
58120141 Manifold, Ø 15 1 90261100 Packing, Ø 15, HP 3 41. 58030022 Connecting R Sal	od 3 e Cover 2
58120141 Manifold, Ø 18 1 90265300 Packing, Ø 18, HP 3 42. 58150074 Crankcase Si 2. 36202551 Valve Cage 3 24. 90507650 Anti-ext. Ring, Ø 13 3 43. 99183700 Screw, M6x14 3. 94737600 Spring, Ø 9.4x14.8 3 90508990 Anti-ext. Ring, Ø 15 3 44. 44211801 Sight Glass 4. 36711501 Valve 3 90511150 Anti-ext. Ring, Ø 18 3 45. 63021265 Cranksfaft, 10 5. 36200366 Valve Seat 3 25. 58605601 Intermed. Ring, Ø 13 3 45. 63021665 Crankshaft, 10 6. 90384100 O-ring, Ø17.13v2.62 3 58605701 Intermed. Ring, Ø 15 3 63021665 Crankshaft, 10 7. 36711501 Valve Assembly 3 58605801 Intermed. Ring, Ø 18 3 63021865 Crankshaft, 10 8. 701002 O-ring, Ø20.24x2.62 3 26.	e Cover 2
2. 36202551 Valve Cage 3 24. 90507650 Anti-ext. Ring, Ø 13 3 43. 99183700 Screw, M6x14 3. 94737600 Spring, Ø 9.4x14.8 3 90508990 Anti-ext. Ring, Ø 15 3 44. 44211801 Sight Glass 4. 36711501 Valve 3 90511150 Anti-ext. Ring, Ø 18 3 45. 63021265 Cranksfaft, 10 6. 90384100 O-ring, Ø17.13v2.62 3 25. 58605601 Intermed. Ring, Ø 13 3 63021665 Crankshaft, 1 7. 36711501 Valve Assembly 3 58605801 Intermed. Ring, Ø 18 3 63021865 Crankshaft, 9 8. 701002 O-ring, Ø20.24x2.62 3 26. 701023 O-ring, 26.7x1.78 3 63021865 Crankshaft, 9 9. 98222600 Valve Cap, M24x1.5x16.7 3 28. 90260100 Seal, Ø 15, LP 3 63029165 Crankshaft, 10 10. 99169000 Plunger Bolt, M5x55 3 90260800 Seal, Ø 15, LP 3 63029165 Crankshaft	
3. 94737600 Spring, Ø 9.4x14.8 3 90508990 Anti-ext. Ring, Ø 15 3 44. 44211801 Sight Glass 4. 36711501 Valve 3 90511150 Anti-ext. Ring, Ø 18 3 45. 63021265 Cranksfaft, 10 (EP1510S, El 6. 90384100 O-ring, Ø17.13v2.62 3 58605701 Intermed. Ring, Ø 13 3 63021665 Crankshaft, 10 (EP1510S, El 6. 90384100 O-ring, Ø20.24x2.62 3 58605801 Intermed. Ring, Ø 18 3 (EP1512S17, 8. 701002 O-ring, Ø20.24x2.62 3 26. 701023 O-ring, 26.7x1.78 3 63021865 Crankshaft, 9 98222600 Valve Cap, M24x1.5x16.7 3 28. 90260100 Seal, Ø 13, LP 3 (EP1513S17, EP18 10. 99169000 Plunger Bolt, M5x55 3 90260800 Seal, Ø 15, LP 3 63029165 Crankshaft 11. 96690500 Washer, Ø 5x11.5x0.4 3 90265000 Seal, Ø 18 LP 3 (EP1811S17) S8040009 Plunger, Ø 13x42 3 29. 58210670 Support Ring, Ø 13 3 46. 91833100 Bearing, Pren 58040109 Plunger, Ø 15x42 3 58210770 Support Ring, Ø 15 3 47. 90409700 O-ring, Ø 55.58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 58210870 Support Ring, Ø 18 49. 91489200 Key	40
4. 36711501 Valve 3 90511150 Anti-ext. Ring, Ø 18 3 45. 63021265 Cranksfaft, 10 (EP1510S, EI (EP1510S,	12
5. 36200366 Valve Seat 3 25. 58605601 Intermed. Ring, Ø 13 3 (EP1510S, EI 6. 90384100 O-ring, Ø17.13v2.62 3 58605701 Intermed. Ring, Ø 15 3 63021665 Crankshaft, 1 7. 36711501 Valve Assembly 3 58605801 Intermed. Ring, Ø 18 3 (EP1512S17, EP18 8. 701002 O-ring, Ø20.24x2.62 3 26. 701023 O-ring, 26.7x1.78 3 63021865 Crankshaft, EP181S17, EP18 9. 98222600 Valve Cap, M24x1.5x16.7 3 28. 90260100 Seal, Ø 13, LP 3 63021865 Crankshaft, EP181S17, EP18 10. 99169000 Plunger Bolt, M5x55 3 90260800 Seal, Ø 15, LP 3 63029165 Crankshaft 11. 96690500 Washer, Ø 5x11.5x0.4 3 90265000 Seal, Ø 18 LP 3 46. 91833100 Bearing, Pren 12. 58040009 Plunger, Ø 15x42 3 58210870 Support Ring, Ø 15 3	1
6. 90384100 O-ring, Ø17.13v2.62 3 58605701 Intermed. Ring, Ø 15 3 63021665 Crankshaft, 1 7. 36711501 Valve Assembly 3 58605801 Intermed. Ring, Ø 18 3 (EP1512S17, 8. 701002 O-ring, Ø20.24x2.62 3 26. 701023 O-ring, 26.7x1.78 3 63021865 Crankshaft, 9. 98222600 Valve Cap, M24x1.5x16.7 3 28. 90260100 Seal, Ø 13, LP 3 (EP1513S17, EP18 10. 99169000 Plunger Bolt, M5x55 3 90260800 Seal, Ø 15, LP 3 63029165 Crankshaft 11. 96690500 Washer, Ø 5x11.5x0.4 3 90265000 Seal, Ø 18 LP 3 (EP1811S17) 12. 58040009 Plunger, Ø 13x42 3 29. 58210670 Support Ring, Ø 13 3 46. 91833100 Bearing, Pren 58040109 Plunger, Ø 15x42 3 58210770 Support Ring, Ø 15 3 47. 90409700 O-ring, Ø 55.5 58040209 Plunger, Ø 18x42 3 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 13. 90358900 O-ring, Ø 12.42x1.78 3 30. 98210000 Plug, 3/8"x13 1 49. 91489200 Key	nm 1
7. 36711501 Valve Assembly 3 58605801 Intermed. Ring, Ø 18 3 (EP1512S17, 2517, 2	1810S)
8. 701002 O-ring, Ø20.24x2.62 3 26. 701023 O-ring, 26.7x1.78 3 63021865 Crankshaft, (EPI513S17, EP18 9. 98222600 Valve Cap, M24x1.5x16.7 3 28. 90260100 Seal, Ø 13, LP 3 63029165 Crankshaft, (EP1513S17, EP18 10. 99169000 Plunger Bolt, M5x55 3 90260800 Seal, Ø 15, LP 3 63029165 Crankshaft (EP1513S17, EP18 11. 96690500 Washer, Ø 5x11.5x0.4 3 90265000 Seal, Ø 18 LP 3 (EP1811S17) 12. 58040009 Plunger, Ø 13x42 3 29. 58210670 Support Ring, Ø 13 3 46. 91833100 Bearing, Pren 58040009 Plunger, Ø 15x42 3 58210770 Support Ring, Ø 15 3 47. 90409700 O-ring, Ø 55.5 58040209 Plunger, Ø 18x42 3 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 13. 90358900 O-ring, Ø 12.42x1.78 3 30. 98210000 Plug, 3/8"x13 1 49. 91489200 Key	mm 1
9. 98222600 Valve Cap, M24x1.5x16.7 3 28. 90260100 Seal, Ø 13, LP 3 (EP1513S17, EP18 10. 99169000 Plunger Bolt, M5x55 3 90260800 Seal, Ø 15, LP 3 63029165 Crankshaft 11. 96690500 Washer, Ø 5x11.5x0.4 3 90265000 Seal, Ø 18 LP 3 (EP1811S17) 12. 58040009 Plunger, Ø 13x42 3 29. 58210670 Support Ring, Ø 13 3 46. 91833100 Bearing, Pren 58040109 Plunger, Ø 15x42 3 58210870 Support Ring, Ø 15 3 47. 90409700 O-ring, Ø 55.9 58040209 Plunger, Ø 18x42 3 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 13. 90358900 O-ring, Ø 12.42x1.78 3 30. 98210000 Plug, 3/8"x13 1 49. 91489200 Key	EP1812S17)
10. 99169000 Plunger Bolt, M5x55 3 90260800 Seal, Ø 15, LP 3 63029165 Crankshaft 11. 96690500 Washer, Ø 5x11.5x0.4 3 90265000 Seal, Ø 18 LP 3 (EP1811S17) 12. 58040009 Plunger, Ø 13x42 3 29. 58210670 Support Ring, Ø 13 3 46. 91833100 Bearing, Pren 58040109 Plunger, Ø 15x42 3 58210770 Support Ring, Ø 15 3 47. 90409700 O-ring, Ø 55.4 58040209 Plunger, Ø 18x42 3 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 13. 90358900 O-ring, Ø 12.42x1.78 3 30. 98210000 Plug, 3/8"x13 1 49. 91489200 Key	1
11. 96690500 Washer, Ø 5x11.5x0.4 3 90265000 Seal, Ø 18 LP 3 (EP1811S17) 12. 58040009 Plunger, Ø 13x42 3 29. 58210670 Support Ring, Ø 13 3 46. 91833100 Bearing, Pren 58040109 Plunger, Ø 15x42 3 58210770 Support Ring, Ø 15 3 47. 90409700 O-ring, Ø 55. 58040209 Plunger, Ø 18x42 3 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 28 13. 90358900 O-ring, Ø 12.42x1.78 3 30. 98210000 Plug, 3/8"x13 1 49. 91489200 Key	3S17, EP1313S17)
12. 58040009 Plunger, Ø 13x42 3 29. 58210670 Support Ring, Ø 13 3 46. 91833100 Bearing, Pren Mean Pr	1
58040109 Plunger, Ø 15x42 3 58210770 Support Ring, Ø 15 3 47. 90409700 O-ring, Ø 55.5 58040209 Plunger, Ø 18x42 3 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 28 13. 90358900 O-ring, Ø 12.42x1.78 3 30. 98210000 Plug, 3/8"x13 1 49. 91489200 Key	
58040209 Plunger, Ø 18x42 3 58210870 Support Ring, Ø 18 3 48. 90164100 Oil Seal, Ø 25 13. 90358900 O-ring, Ø 12.42x1.78 3 30. 98210000 Plug, 3/8"x13 1 49. 91489200 Key	um 2
13. 90358900 O-ring, Ø 12.42x1.78 3 30. 98210000 Plug, 3/8"x13 1 49. 91489200 Key	3x3.53 1
	(62x10 1
14. 36211366 Outlet Valve Seat 3 31. 96738000 Gasket, 17.5x23x1.5 1 <u>50. 98210500 Oil Dipstick</u>	1
	1
15. 36211276 Outlet Valve Poppet 3 32. 98217600 Plug, 1/2" BSPx10 1 51. 90392550 O-ring, Ø 113	97x2.62 1
16. 94733300 Spring, Ø 6.2x10.4 3 33. 96751400 Gasket, Ø 21.5x27x1.5 1 52. 58160022 Rear Cover	1
17. 36211151 Outlet Valve Cage Guide 3 34. 96698000 Washer, Ø 7.5x15x0.5 3 53. 98204100 Plug, 1/4"x9	1
18. 36719301 Complete Outlet Valve 3 35. 58210582 Gasket, Ø 3x94 1 <u>54. 701013 O-ring, Ø 10.8</u>	2x1.78 1
19. 701016 O-ring, Ø 15.6x1.78 3 36. 58010022 Crankcase 1 55. 98196600 Plug, 1/8"x8	1
<u>20. 98213700 Outlet Valve Cap, M18x1.5x10 3</u> <u>37. 58210451 Drip Cover 1</u> 56. 99303700 Screw, Hex H	
21. 99317500 Screw, M8x60 8 38. 90156550 Oil Seal, Ø 15x24x5.7 3 57. 96701600 Washer, Ø 8.	4
22. 44100251 Head Ring, Ø 13 3 39. 58050066 Piston Guide 3 58. 50200074 Pump Foot	2
63101051 Head Ring, Ø 15 3	
63101151 Head Ring, Ø 18 3	

REPAIR KITS TORQUE SPECS*


KIT NO.	K269	K270	K271	Ø 13		Ø 15		Ø 18	
1111 1101	11200	11210	11271	K272	K275	K273	K276	K274	K277
ITEM NO'S INCLUDED IN KIT	2, 3, 4, 5, 6, 13, 14, 15, 16, 17, (7), (18)	8, 9, 19, 20	38	22, 23, 24, 26, 28	22, 23, 24, 25, 26, 28 29	22, 23, 24, 26, 28	22, 23, 24, 25, 26, 28 29	22, 23, 24, 26, 28	22, 23, 24, 25, 26, 28 29
NUMBER OF ASSY'S IN KIT	6	6	3	3	1	3	1	3	1
NO. OF CYLINDERS KIT SERVICES	3	3	3	3	1	3	1	3	1

Position	FtLbs.	Nm.
9	96	130
10	4.5	6
20	26	35
21	14.8	20
30	30	40
32	30	40
43	7.4	10
53	14.8	20
55	9.6	13
56	14.8	20

*Decrease torque by 20% if threads are lubricated.

**Use Loctite 542 Red

DIMENSIONS



Ref 300919 Rev.A 02-13

